



Description: Headlight

Part Number: 111009 - 111010

Application: 2003-2006 Chevy Silverado (1500-2500-3500)



No tools are needed for install.



Step 1: Locate the pin located on the top of the headlight assembly



Step 2: Pull the pin straight out to loosen the headlight assembly.



Step 3: Pull the headlight straight out of the housing.



Step 4: Disconnect the headlight wire harness from the high and low beam light bulbs.



Step 5: connect the wire harness to the new anzo headlight. Bulbs are supplied with the headlight.



Step 6: install the headlight back into the housing, slide the pin back in place.



Step 7: adjust the headlight to your vehicle specs.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.