



Description: Projector Halo Headlights
Part Number: 111015 - 111016
Application: 98-04 Chevy S-10 / Blazer



Tools Needed:
4 Splicer's

Step 1: Locate the two clips
located at the top of the headlight.

Step 2: Remove the two clips
which hold the headlight to the
frame.



Step 3: Pull the headlight
assembly straight out of the
housing.

Step 4: Unplug the high and low
beam harness from the bulbs.



Step 5: Remove the turn signal
socket from the headlight.

Step 6: Take the anzo headlight,
splice in the red wire to blue
and red wire to black
to power up the halo's



Step 7: Plug the headlight harness to the ANZO headlight



Make sure all functions work properly before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.