



Description: Crystal Clear Headlights
Part Number: 111022 - 111076
Application: 2002-2005 Dodge Ram (1500-2500-3500)



Tools Needed:
10mm deep socket
Phillips Screw Driver

Step 1: Remove the plastic screws
to remove rubber shroud.

Step 2: Remove the upper and
lower 10mm bolts.



Step 3: Remove the bolt located
underneath the headlight.

Step 4: Pull the headlight
assembly straight out.



Step 5: Pull the headlight
exposing the sockets.

Step 6: Pull the turn signal socket
out of the housing.

Step 7: Unplug the socket from
the headlight bulb.



Step 8: Place the turn signal bulb into the new Anzo housing.

Step 9: Plug the headlight socket to the bulb.



Step 10: Slide the new ANZO headlight into the housing.

Make sure all functions are working properly before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.