



Description: Head light
Part Number: 111128-111129
Application: 2008-up Ford F250-F350-F450



Tools needed: 8mm socket,
wire splicer, electrical tape.



Step 1: Remove the top 8mm
screw holding in the head
light.



Step 2: Remove the two 8mm
screws on the side of the
headlight.



Step 3: Under the head light
housing there will be a 8mm
screw that needs to be



Step 4: Unclip the sensor from
the headlight.



Step 5: Unclip the turn signals
and head light harness




Step 6: Pull out the new Anzo
headlight and twist the two
loose black wires together.



Step 7: Twist the two loose
red wires together.






Step 8: Locate the parking lamp marker and remove the cover to expose the purple and black wire.




Step 11: Put in the new Anzo headlight.



Step 9: Splice the red wires to the purple and the black to the black wire.



Step 12: Test all functions making sure of proper installation before driving.



Step 10: Plug in the headlight and parking light harness into the new Anzo head light.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.