



Description: Tail Lights
Part Number: 311047-311080-311081
Application: 2007.5-2009 Chevy Silverado



Tools needed: Phillips
screwdriver



Step 1: Under the vehicle bed
unplug the wire harness for
the tail light.



Step 2: unclip the wire from
the plastic clips.



Step 3: Use the phillips
screwdriver to remove the two
screws holding in the tail light.



Step 4: Remove the tail light.



Step 5: Pull the wire out from
under the bed.



Step 6: Peel off the protective
cover from the resistors and
place in the two holes onto
the frame of the body.



Step 7: Plug the resistors in
and the wire harness into the
circuit board under the bed.



Step 8: Test all functions
making sure all functions work
before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.